


Rubber D-Style Bumpers

Removal



CAUTION: Discard ALL used fasteners and replace with new. If using a fastener that does NOT have preapplied thread lock, apply a medium-grade liquid thread lock.

1. Remove bolts and nuts from D-bumper through access holes.
2. Set D-bumper and retainer plate aside.



Installation

1. Insert retainer plate into D-bumper.
2. Secure D-bumper with new bolts and nuts.
3. Tighten nuts.

Utilimaster Customer Service

574-848-2200

Email: Parts@Utilimaster.com

Rubber D-Bumpers, December 2014

©Utilimaster Corp., 603 Earthway Boulevard, Bristol, Indiana 46507 USA